

**NEWWAY SP**

**Ferrari**

**OFFICIAL LICENSED PRODUCT**

Made in France by **TEAM TEX**

**Rue du Claret - Z.I. de Montbertrand**

**38230 Charvieu - France**

**Tél. +33 (0)4 72 46 98 98 - Fax +33 (0)4 72 46 98 70**

V5807



**Ferrari**

- PLEASE READ THOROUGHLY BEFORE COMMENCING INSTALLATION AS AN INCORRECT INSTALLATION COULD BE DANGEROUS.
- DO NOT USE THIS CHILD SEAT IN PASSENGER SEATS EQUIPPED WITH AIRBAGS.
- This child seat **must only** be installed in a forward facing position in passenger seats.  
**Do not** use on side facing or rear facing seats.
- **Never** use this child seat without fastening the child's harness correctly, and **never** attempt to use it without fastening it into the car as described in these instructions.
- **Do not** add to or modify the seat in any way.
- In the event of an emergency it is important that the child can be released quickly. This means that the buckle is not fully tamperproof and so your child **must** be taught **never** to play with the buckle.
- **Do not** leave your child unattended in the seat at any time.
- It is recommended that this car seat should be changed when it has been subjected to violent stresses in an accident or has become badly worn. Periodically inspect the harness for wear, paying particular attention to the attachment points, stitching and adjusting devices.

- Ensure that no part of the seat is trapped in a door or folding seat. If your car has a folding rear seat, ensure that it is correctly latched in the upright position.
- Car interiors can become very hot when in direct sunlight, it is therefore recommended that the child seat is covered when not in use. This prevents components, particularly those attached to the child seat, becoming hot and burning the child.
- Luggage and other heavy or sharp objects should be secured in the car. Loose objects are liable to cause injury in the event of an accident.
- The safest seating position for a child car seat is on the rear seat of a vehicle.


This child seat **must only** be installed in a forward facing position.

This seat is classified as:


Group 1 for children weighing from **9kg to 18kg**  
(9 months - 4 years approx.)

Group 2 for children weighing from **15kg to 25kg**  
(4 - 6 years approx.)


Group 3 for children weighing from **22kg to 36kg**  
(6 - 11 years approx.)



SET UP FOR USE BY  
**9-18kg** CHILDREN  
GROUP 1




SET UP FOR USE BY  
**15-25kg** CHILDREN  
GROUP 2



SET UP FOR USE BY  
**22-36kg** CHILDREN  
GROUP 3




FRONT OF SEAT



REAR OF SEAT

3

## the type of approved seat belt you must have



Your child seat can only be installed forward facing using a lap and diagonal seat belt.

**DO NOT USE THIS CHILD SEAT  
IN PASSENGER SEATS  
EQUIPPED WITH AIRBAGS**

4

## legal requirements

This child seat is approved to ECE R44.03 and is **ONLY** suitable for use with a 3 point lap and diagonal seat belt, approved to UN/ECE Regulation No.16 or other equivalent safety standards.

### front Seat

---

Anyone, especially children, travelling in the front seat of a car **must** be properly restrained. Children under three years **must** use a suitable approved restraint designed for their weight.

### rear Seat


---

All adults and children **must** use seat belts or child restraints where they are fitted in the rear of a car and are available for use.


If the appropriate restraint is not available, children from 3 years **must** wear an adult seat belt if available.

- In an emergency your child can be released quickly by pressing the red button on the harness buckle.
- This user guide should be stored in the seat cover pocket.
- When the child seat is not in use, it is recommended that it is fastened into the car with a seat belt to avoid being thrown about in the event of an accident.
- If you travel with passengers using both the front and rear seats, the lighter occupants should be in the rear seats and the heavier occupants in the front of the vehicle. When a child is in the front seat, the lighter passenger should be behind the child.
- **Do not** allow the child seat to come into contact with corrosive substances e.g. battery acid.


## securing the harness



Place the left hand harness connector behind the right hand one. They should slot together neatly.




Push the harness ends into the hole in the buckle at the top of the crotch strap. You will hear and feel a 'CLICK' when it is secure. Check by attempting to remove the connectors by pulling the webbing above and below the buckle. Periodically check that your child has not released the buckle. (To release the harness, press the red button down.)



## tightening the harness

---




Pull gently on the harness adjuster to take up any slack.

A loose harness is **dangerous**, so it should be checked **every** time the seat is used.

It is recommended that there is just enough room to insert two fingers between the shoulder straps and the child's chest.

## loosening the harness


---



If the harness is too tight, loosen it by first pressing the tab at the front of the seat, and then pulling both straps, as shown. **Do not** pull on the shoulder pads, as these are fixed in length.

## adjusting the shoulder height

1




The harness has 3 height positions.

The straps should go into the slots nearest to the top of your child's shoulders.

**IMPORTANT**

If your child's shoulders are between two pairs of slots, **always** use the higher position.

2



To adjust the shoulder straps of the harness, remove one of the shoulder straps from the metal retaining yoke located at the back of the seat. Leave the other one in place for reference.

3




Pull the shoulder strap through the harness slot in the shell and cover, then pull through the shoulder pad.

## 6


## the harness

4



Pull shoulder pad back through harness slot in cover and shell, and re-locate to desired harness slot.

5




Feed the shoulder strap back through the shoulder pad, then through the same slot, and re-attach to metal yoke at rear. Repeat the same procedure for the shoulder strap and pad on the other side. Make sure there are **no kinks or twists** in the straps.

## 7

## using the head support

1




The adjustable head support is designed to provide side impact protection for your child (when the seat is used with the backrest).

The head support should be positioned just above your child's shoulders.

7

## using the head support

2



To adjust the height, unscrew the red locking device located at the top back of shell. Move up or down to the desired position. Then re-tighten the red locking device, making sure that there is no movement in the head support.

The head support can be removed to wash the cover. Please see care & maintenance section.

8


## fitting your child seat into your car

### WARNING:


Do not use this child seat in passenger seats fitted with airbags.  
Do not use on rear-facing or side-facing vehicle seats.

To set up for use from 9kg to 18kg


1




Place the child's car seat on a passenger seat with a 3 point seat belt. Make sure the child seat is facing towards the front of the car.



Pull the lap and diagonal sections of the car seat until fully extended. Guide the seat belt around the side panel of the car seat making sure that the lap belt is **below** the arm rest of the seat base.




Then feed both lap and diagonal belt into the side slot, around the plastic back panel (over the harness) and back through the opposite slot. Pull the belt around the seat and fasten in the normal way making sure that the lap section is below the arm rest and the diagonal section goes through the red guide. Make sure that there are no kinks or twists in the car seat belt.



Put your knee on the child seat to push it right down into the car seat. You should then pull upwards simultaneously on both the lap and diagonal belts. Your car seat should now be fixed securely.



To check that the seat is fixed securely, tug the top of the shoulder straps there should be little or no forwards movement.

To set up for use from 15kg to 25kg




Your child will be secured using the vehicle's seat belt. It will therefore be necessary to remove the harness fitted to the child seat before use.

Turn the seat upside down and remove the blue plastic clips from the ends of both of the shoulder straps. Feed the straps through the bottom of the child seat.



Pull the shoulder straps through the buckle connectors, then pull both shoulder straps and shoulder pads through the back of the seat.


3



Remove the shoulder straps from the metal yoke.


Pull the harness adjuster until the metal yoke is tight against the back of the seat base.

4




The end of the harness adjuster which is left can be fed back into the slot in the cover for storage for future use.

5



Remove the crotch strap by twisting and feeding the metal retaining keeper through the BOTTOM of the child seat and up through the seat's upholstery.

6



To fit the child's car seat, place it on a passenger seat with a 3 point seat belt. Make sure it is facing towards the front of the vehicle.

7




Pull the lap and diagonal sections of the car seat belt across and secure it in the normal way.

Make sure that there are **no kinks or twists** in the car seat belt.

The lap belt should be routed **under** both the arm rests of the child seat and the diagonal belt routed **over** the armrest as shown. The diagonal belt will be kept away from the child's neck by passing under the head support.


## To set up for use from 22kg to 36kg

1



The child seat can be used as a 'booster seat' by removing the back section. If you have not already removed the child's harness, do this first. (Refer to diagrams 1 to 5 on pages 14 and 15). The back section of the seat is removed by pushing the back of the seat away from the base of the seat.

2




Attach the diagonal belt clip, by threading the loose strap through the slot at the side of the seat base.

**IMPORTANT**

This should be fitted on the **same side** as the vehicle seat belt buckle when the seat is installed in the car.

3



Place the child car seat on the passenger seat with a 3 point seat belt. Make sure it is facing towards the front of the car.


4



Pull the lap and shoulder sections of the vehicle seat belt across and secure it in the normal way.

The lap belt should be routed **under** both the arm rests of the child seat, and the diagonal belt routed **over** the armrest as shown.

5



The red belt clip can be used to position the diagonal belt securely on the child's shoulder, away from the neck. Pass the strap **behind** the child's back, so the clip rests on the child's shoulder, then feed the diagonal belt through the clip. Adjust the strap length so the clip holds the belt securely on the shoulder.

**WARNING:** PLEASE ENSURE THAT THE RED BELT CLIP AND WEBBING DO NOT INTERFERE WITH THE VEHICLE SEAT BELT

However safe a child seat is, however well built it is, your child's safety depends on you.


Read this final checklist once you have fitted your child seat in your car.

1. Check that you have adjusted the harness to suit your child.  
A fitting for winter clothes will be too loose for a child wearing summer clothes.
2. Check you have installed your child seat properly using a 3 point lap and diagonal belt.  
See section 8, fitting your child seat into your car.
3. Check that your child seat is secure before each journey.  
**REMEMBER:** mis-using your child seat will reduce the protection and safety you offer your child.

**IF YOU ARE UNSURE ABOUT THE FIT OF YOUR CHILD SEAT  
PLEASE VISIT YOUR LOCAL MOTHERCARE STORE FOR ADVICE**


AFTER YOU HAVE USED THE CHILD SEAT FOR AN OLDER CHILD (GROUP 2 OR 3) YOU MUST FOLLOW THE GUIDELINES BELOW WHEN RE-USING THE SEAT FOR A YOUNGER (GROUP 1) CHILD.

1



Remove the diagonal belt clip.


2



Re-fit the back of the child seat. To do this, lay the seat back flat. Engage the two locating pegs and lift upwards as shown.


Then press down firmly on the back of the seat so that the two pegs engage securely.

3




Feed the metal keeper of the crotch strap through the slot in the cover and through the rear of the two slots in the plastic base.

4




Make sure that the metal keeper is securely engaged against the seat base.

5




Re-attach the shoulder straps to the metal yoke as shown.

6



Feed both shoulder straps and pads through the harness slots at the correct height for your child. The shoulder pads are an important safety feature, and **must** be fitted with the friction side against your child's shoulders.

7




Feed the shoulder straps through the buckle connectors, then into the slots in cover and base at the sides of the seat.

10

returning the seat to its configuration for younger children


8



Fit the blue plastic clips onto the ends of the shoulder harnesses. Check all fittings are secure before use.

11

care of your product



removing the fabric cover

- The fabric cover can be removed from the seat. Remove the child's harness refer to diagrams 1 to 5 on pages 14 and 15.

Then release the elasticated edges of the cover from the seat.

Remove the head support by turning the red locking device whilst applying downward pressure as shown.

cleaning the seat

- The harness and plastic parts can be sponged with a mild detergent and warm water.

Ensure no soap gets into the buckle or adjusters.


**Do not** use chemical cleaners or bleach on the harness straps. Dry thoroughly before use.

Your child seat and its cover have been carefully designed, manufactured and tested to the highest safety standards.

**Do not** put your child's safety at risk by using without a seat cover. The seat cover should not be replaced with any other than the one recommended by the manufacturer, because the cover constitutes an integral part of the restraint performance.

The safety of this seat may be compromised by the use of accessories not approved by manufacturer.

The replacement parts listed below are available for your product. In the event that you require any of these parts, please contact the manufacturer (details on back page).



If you have a problem with this product or require replacement parts, please contact the manufacturer (details on back page).