




booster seat
user guide



IMPORTANT. KEEP FOR FUTURE REFERENCE

introduction


This booster seat is designed to be fitted to a suitable chair*, to raise the height of your child when sat at a table.

WARNING: It is recommended that the booster seat be used in the upright position only by children capable of sitting upright unassisted (around 6 to 9 months). The product is suitable for children up to approximately 4 years.

* Refer to page 4 safety notes for information on suitable types of chairs.

parts checklist

fig 1



seat & harness

fig 2




securing strap

preparation for use

the securing strap

fig 3




1. Disengage the buckle of the securing strap by squeezing the fastener prongs and pulling apart.

preparation for use

fixing to the chair


fig 4



Position the booster on the chair*, wrap the securing strap underneath and fasten the buckle.

* Refer to page 4, safety notes for information on suitable types of chairs.

fig 5




Tighten the securing strap by pulling on the free end to remove any slack.

Always check that it is secure and stable before placing your child in the seat.

On cushioned chairs, it may be necessary to further tighten the strap once your child is in the seat.

the harness


fig 6



To fasten


Insert both fasteners securely into their respective clasps

fig 7



Adjust the waist strap length by pulling on the free end to remove unwanted slack

fig 8



To release

Squeeze the fastener prongs and pull apart.


Your child should be securely harnessed at all times and should never be left unattended, even for short periods.

care of your product

- The booster can be cleaned by sponging with warm water and a mild detergent. A mild disinfectant may be used.
- Stubborn marks may be removed with a non-abrasive cream cleaner. Never clean with abrasive, ammonia based, bleach based or spirit type cleaners.
- Periodically check for damage, including internally, and discontinue use if any part is damaged or broken.

safety notes

fig 9



The recommended type of chair is as shown left, with four legs, a high backrest, and firm seat.

If the chair has a cushioned seat, check the securing strap periodically to ensure it has not loosened.

Do not use the booster on a table top, stool, swivel chair, folding chair or any other type of chair to which the booster cannot be firmly secured.

- **WARNING:** Prevent serious injury or death from falls or sliding out:
- The booster must be fully secured to the seat before placing a child inside.
- Always secure the child in the restraint until the child is able to get in and out of the booster seat without help (about 2½ years old)
- When using the booster at a table, ensure the child cannot push against the table or another chair, and tip the booster and chair over.
- Keep away from trailing cords flexes, electric irons, ornaments and other such hazards.
- Do not use close to any source of heat.
- Never use the booster in a vehicle as a car seat.
- Do not move the booster or chair with the child inside.
- Do not use if any part is broken, damaged or missing.
- If the booster is used by someone unfamiliar with it e.g. grandparents always show them how it is used.
- Never leave your child unattended, even for the shortest time.